

National Guard Products



Door Sweeps

Installation Instructions

1. Cut sweep to fit.
2. Close door. Hold sweep at bottom of door. Tap down until contact is made between the sweep and threshold.
3. Mark screw holes.
4. Drill pilot holes for screws using a 7/64" drill bit.
5. Install with screws provided.
6. Adjust position so sweep does not impede proper closing and latching of door.



UL 10C Positive Pressure Tested Gasketing Material for Fire Doors. Also Classified in accordance with UBC 7-2(1997).



UL10B Gasketing Materials for Fire Doors.
Intended for Application to Classified Steel fire doors rated up to 3 hours and Wood type fire doors up to 1 1/2 hours.

Smoke and Draft Control door bottom (Category H) meets requirements of UBC 702(1997) part 2, NFPA 105, IBC, and UL 1784 intended for application to classified "S" label doors.