



KSP

Killeen Security Products
www.iccore.com

Cam Installation for Housings w/Screw-On Nest



Instructions:

K series cams are installed as shown in the above image. Screws with pre-applied thread lock need to be used to ensure proper function. If screws are removed, a suitable thread lock product must be re-applied or use new screws with the pre-applied thread lock patch as provided by KSP. A housing installation tool does a good job of holding the drive assembly while tightening cam screws.

33 Hermon Street
Worcester MA 01610

Phone: 1-800-577-5397
Fax: 1-508-753-2183
E-mail: sales@iccore.com