

1-800-647-7874



139A, 139BR, 139DKB, 139SS Astragal



## Installation Instructions

- 1. Cut astragal to fit.
- 2. Position on door and mark screw holes.
- 3. Drill pilot holes for screws using a 9/64" drill bit.
- 4. Install with screws provided. Adjust position so astragal does not impede proper closing and latching of door. 4/05