

Thermal Barrier Threshold



Installation Instructions

- 1. Cut threshold to size required.
- 2. Notch around door frame if desired.
- 3. Attach to floor surface with fasteners provided.
- 4. Caulk around base of threshold for moisture control.

4/05